

尺寸：40mm×175mm

**PS：**重点字体已标注红色,印刷出来也需是红色。

[illegible]

# KRECO

## Multifunctional Smart Glasses

### KREC-K1-3 Instruction Manual

**• Directions To Use**

(1)Glasses switch machine and matching.

Turn on the bluetooth device such as the mobile phone,pres and hold the power button for 3 seconds,the glasses voice prompts [Starting], and the LED indicator light keeps flashing at this time;after the connection with the bluetooth device is successful,the indicator light goes out.  
(For detailed operation, please refer to the bluetooth connection diagram on the last two pages)

(2)Charging and alarm.

- Low power alarm:voice prompts [low battery charge please],the LED indicator continues to blink 3 seconds interval 5 seconds.
- Low power off,voice prompts [shutdown], the LED indicator for 1second long.
- During charging,the red light of the LED indicator is long.
- When the charging is completed,the LED indicator red light will automatically go out.

(3)Functional Operation

The glasses is connected, and in the standby mode, press the power button twice to wake up the voice assistant.

**• Disclaimer**

First of all,thank you for using our products! Please read this manual before using and use this product correctly.For the better service.changes due to the performance and functionality of the product will be revised without notice.Open-ear smart audio glasses.This product is a Bluetooth speaker withstereo function,easy to operate, stylish and practical,easy too carry.

**• Product Introduction**

Multifunctional smart glasses use Bluetooth chips, compatible with mainstream brand mobile phones and tablets and other Bluetooth devices, support aptX audio decoding technology, achieve CD-level high-quality sound quality, long-lasting battery life, left and right double speakers, open directional pronunciation, and barrier-free reception of external sounds. The surrounding environment information can be obtained at all times, which is safe, intelligent, healthy and convenient.

**• Packing List**

Audio glasses,Glasses charging cable, Instruction manual,Glasses cleaning cloth.

**• Directions To Use**

(1) Making and receiving calls.

- Make a phone call: Press the power button three times in succession, and when you hear the prompt tone,call "" (the name in the address book) or the phonenummer of the other party, then you can make a phone call;
- Answer the call: Single press the power button to answer the call;
- Hang up the call: Single press the power button to hang up the call;
- Redial: Press the power button three times in succession to redial the last call record;

2. Listen to music.

- Accurate song selection: Press the power button two times and say "Play music" after hearing the prompt sound (such as Shanghai Tang), then you can call and play the songs inside the phone;
- Random play: Press the power button two times, and when you hear the prompt sound, say "Play music",you can call and randomly play the songs inside the phone;
- Play the next song: Press the power button two times;
- Play the last song: Press the power button three times in a row;
- Pause playback: Single press the power button.

**△ Caution**

Please follow the relevant laws and regulations and do not use headphones in the following environments.

- Such as gas stations, oil depots, chemical warehouses and other environments where flammable and explosive gas or chemicals are stored, it is strictly prohibited to use the equipment.
- Do not use this device in hospital operating rooms, emergency rooms, intensive care units, etc.; in order to avoid interfering with the work of medical equipment, please keep away from pacemakers, hearing aids, cochlear implants and other medical equipment when using this device, please keep this More than 15 cm between the device and the pacemaker.
- To use this device near personal medical equipment, consult your physician and device manufacturer.
- Follow all safety warnings and regulations regarding the use of this device while driving.
- During thunderstorms, do not use it outdoors in order to avoid lightning accidents.
- When charging, do not make a call while charging.

3. Switch between playing music and making phone calls.

- When you need to make a call while listening to music,first press the power button to pause the music,and then press the power button twice to make the call after hearing the prompt tone.

4. Navigation.

- Turn on the navigation: press the power button twice, say "Help me navigate to the "" position" after hearing the prompt, and then perform voice operations according to the prompt sound of the glasses;
- Turn off the navigation: Press the power button twice, and then say "Exit the navigation" after hearing the prompt tone.

5.Offline camera function,etc

- When the camera is turned on,single press the power button to take a photo.

**• Tips**

- Please read the instructions carefully before using this product and keep this manual.
- For the first time,please fully charge this glasses.
- If the glasses does not charge for a long period of time (more than two weeks),charge it before use.

**• Warning**

- Do not dismantle or repair this product for any reason,as this may result in fire. Electronic breakdown or even complete damage to the product.
- Do not place the device in an environment where the temperature is too low or too high(below 0°C or above 45°C).
- Do not get the product wet with liquid or immerse in liquid.
- Do not expose the glasses to the sun for a long time,otherwise it will be easily deformed,broken and broken.
- Do not place the magnetic end of the charging cable close to metal objects to prevent the risk of short circuit caused by magnetically attracting metal objects.

**• Important Safety Information**

- Before using this product, please read all safety information to ensure correct and safe use.
- Using a power supply, charger or battery not approved by the original manufacturer may cause fire, explosion or other hazards.
- Please use the accessories approved by the manufacturer and matched with this model of equipment.

**Schematic diagram of Bluetooth connection**

① Go to settings

② Select the Bluetooth option

**• Product warranty certificate**

During the product warranty period, non-human-damaged performance failures can enjoy the following three-guarantee services:

- Within 7 days from the date of receipt, if the product has a performance failure that is not artificially damaged, the user can choose to return the payment or replace the product with the same model and specification.
- Within 15 days from the date of receipt, the user can choose to replace the product with the same model and specification if the product has a performance failure that is not artificially damaged.
- Within one year from the date of receipt of the product, if the product has a performance failure that is not artificially damaged, the user can send it to the merchant for repair.

4.Use accessories approved by this manufacturer and compatible with this model.Please use the device within the temperature range of 0°C-35°C, and store the device and its accessories within the temperature range of -20°C - 55°C.When the ambient temperature is too high or too low,it may cause equipment failure.

5.If the device uses a non-removable internal battery,do not replace the battery yourself to avoid damaging the battery or device.The battery can only be replaced by an authorized service center.

6.If charging is complete ,disconnect the charger from the device the unplug the charger from the power outlet.Do not charge more than 12 hours.

7. Please keep the device dry.

8. If the equipment or any other parts do not work properly, please do not repair the product by yourself.

9. When connecting to other devices, please refer to the connection method in the user manual, and do not connect any unsuitable devices at will.

**Schematic diagram of Bluetooth connection**

③ Make sure the Bluetooth switch is ON, search for the device name: KREC-K1-3, click the Bluetooth name to enter the connection.

④ The Bluetooth connection is successful.