



■ Description

KRE-BSA series reminder system of baby seat alarm is an electronic device designed to sense status of baby and remind driver to check the baby seat as they exit their vehicles. System will generate the anti-abandon alerts when driver is leaving vehicle.

■ Features and Applications

- Prevent child from hot car deaths
- Visual and audible alarm
- Anti-abandon warning after flame out if child is still in seat
- Anti-abandon warning after unfasten seat belt if child is still in seat
- Warning for babies leave seat while driving
- Low sensor pad & seat belt detection kit battery warning
- The display module supports 5 DC / 2A USB power/ charger output
- DIY installation, installed without wiring
- Adopts one-way communication mode. The seat sensor pad and seat belt detector are only responsible for sending the corresponding status, and the display module is only responsible for receiving the status of the seat sensor module and giving the corresponding alert.
- The three parties cooperate to complete alertly the status of the baby/children seat
- Carrying baby weight from 2.5 to 36 kg
- Complying with 2014/53/EU regulations(EMC)
- Plug & play: intervention of a specialized technician not required
- Wireless sensor: the sensor and the display communicate wireless
- Seats: support numbers of seats, as per design.

■ Functions

• ANTI-ABANDON WHEN THE CAR IS OFF

If the car is off and the baby is still in the seat, the acoustic alarm will activate and the display will flash red.

• THE BABY IS NOT PROPERLY PLACED IN THE SEAT WHEN TRAVELLING

If the kid not properly seated, moves or he leaves the seat, the device will emit three alarm BEEP and the display will become RED.

■ Alarm Status



The display is green light by default when power on, the following conditions are been detected to prevent children left behind:

- When pressure sensor is in the sitting, the device detects that ACC changes from on to off, the display light will flash, and buzzer bi-bi-bi sound to remind driver.
- When the pressure sensor is in the sitting, the device detects the ACC changes from ON to OFF and the driver's safety belt buckle is pull out, the display light will flash and buzzer bi-bi-bi sound until pressure sensor is not under pressure.
- While in the remind process, if the device detects pressure sensor is not sitting or safety belt is buckled again, the buzzer sound and flashlight will be turn-off automatically.

■ Remark

- 1) safety model number differs from the order number, part number, and shape number as per respective OEM/ODM/OBM.
- 2) See more details from KRE-BSA-UserManual.PDF



Kreco is not responsible for any error, and reserves the right to make changes without notice. Please visit our website at <http://www.vehicleplayer.com> for the most up-to-date specifications and contact information.