智能眼镜中英文说明书（按键款）

尺寸：40mm×175mm　　PS：重点字体已标注红色,印刷出来也需是红色。

KRECO

多功能智能眼镜

(J2使用说明)

KRE-K2-1使用说明

1.长按开机键**3S**开机

2.按开机键**2次**下一曲

3.按开机键**3次**上一曲

4.按**4次**切换中英文模式
（在开机不连接设备下使用）

•声明

首先对您使用本公司的产品表示感谢!在使用之前请先详细阅读此说明书，正确使用此产品。为了更好的服务，本用户手册的内容可能变更。因为产品的性能和功能而发生的变更将不做另行通知。

•产品简介

多功能智能眼镜采用蓝牙芯片,兼容主流品牌手机和平板电脑等蓝牙设备,支持aptX音频解码技术,达到CD级高品质音质,持久续航,左右双喇叭,开放式定向发音,无障碍接收外界声音,可时刻获取周围环境信息,安全、智能、健康、 便捷。

多功能智能眼镜，本产品是具有立体声音响功能的蓝牙眼镜,操作简便，美观实用，便于携带。

•包装清单

智能眼镜、智能眼镜充电线、
使用说明书、眼镜清洁布

• 提示

1.使用本产品前请仔细阅读说明书，并保留本说明书。
2.首次使用，请先将本产品充满电。
3.如果产品长期（超过两周）不充电，使用前请对其充电。

• 警告

1.请勿以任何理由拆除或维修改装本产品,否则可能会导致起火,电子击穿甚至彻底损坏本产品。
2.请勿将设备置于温度过低或过高（0℃以下或45℃以上）环境下。
3.请勿将产品接触液体甚至浸泡在液体里。
4.不能将眼镜放在阳光下长时间曝晒，否则容易变形、老化、折断。
5.请勿将充电线磁吸端靠近金属物体,防止磁吸金属物体后引起的短路危险。

• 重要安全信息

1.在使用本产品前，请先阅读所有安全信息以确保正确和安全使用。
2.使用未经原制造商认可的电源，充电器或电池，可能引发火灾，爆炸或其他危险。
3.请使用本制造商认可且与此型号设备配套的配件。

4.请在温度0℃~35℃范围内使用本产品,并在温度-20℃- 45℃范围内存放设备及其配件。当环境温度过高或过低时,可能会引发设备故障。
5.若设备使用不可拆卸的内置电池,请勿自行更换电池,以免损坏电池或设备。电池只能由授权服务中心更换。
6.如充电完毕,请断开充电器与本设备的连接,并从电源插座上拔掉充电器。连续充电时间请勿超过12小时。
7.请不要将旧电池扔进生活垃圾中进行处理,若电池处理不当可能会导致电池起火和爆炸。请遵守当地规定处理本设备,电池及其他附件。
8.电池禁止拆卸,撞击,挤压或投入火中,若出现严重膨胀,请勿继续使用。
9.请勿将电池金属触点短接,导致短路危险,避免电池过热引起烫伤烧伤等人身伤害。
10.请勿置于高温环境中,电池过热可能会引起爆炸。
11.请勿拆解,碰撞,挤压电池,避免引起漏液,过热,爆炸。
12.请勿将电池投入火中,否则会引起火灾或爆炸。
13.若电池出现严重膨胀,请勿继续使用。
14.请保持设备干燥。
15.若设备或其他任何部件不能正常工作,请勿自行维修任何产品。

•产品参数

镜架材质：PC
镜片材质：PC
镜片颜色：透明变色
　　墨镜色(多种选择)
蓝牙协议：5.0
充电时间：2H
使用时间：6H
待机时间：180H(蓝牙连接状态)
电池容量：120mAh
声　　道：双喇叭、立体声
充电电压和电流：DC5V/1A
最大充电电流达160mAh

温馨提示：
充电时间：1-2小时。
长期不使用时，每2个月对电池至少充电一次。

16.连接其他设备时,请参考用户手册的连接方法,不要随意连接不配套的设备。

⚠为避免听力受损,请勿长时间使用高音量。

⚠ 警告

请遵循相关法律法规,不要在以下环境使用。
• 如加油站，油库，化学仓库附近等存储有易燃易爆油气或化学品的环境,严禁使用设备。
• 请勿在医院手术室、急诊室、深切治疗部等场所使用此设备; 为避免干扰医疗仪器工作,使用此设备时请远离心脏起搏器、助听器、植入耳蜗等医用设备,请保持此设备和起搏器之间超过15厘米的距离。
• 若要在个人医疗设备附近使用此设备,请咨询医师和设备制造商。
• 请遵守有关驾车时使用此设备的所有安全警告和规定。
• 雷雨天气时,为避免雷击事故,请勿在室外使用。
• 充电时,请勿边充电边通话。
• 请勿在浴室等高湿度的地方使用充电器,否则会导致触电,人身伤害,起火和充电器损坏。
• 请遵守在任何环境里明确禁止使用的相关法律规定。

•使用说明

（一）眼镜开关机与配对
1、开机与配对：
打开手机等蓝牙设备,长按电源键3秒,眼镜语音提示【正在开机】,此时LED指示灯持续闪烁；与蓝牙设备连接成功后,指示灯熄灭。
(详细操作请参考最后一页的蓝牙连接图)

2、关机：
长按电源键3秒,语音提示【正在关机】,即与手机断开连接。

（二）充电与报警
1、低电报警,语音提示【电池电量低请充电】，LED指示灯持续闪烁3秒间隔5秒。
2、低电关机,语音提示【正在关机】,LED指示灯长亮1秒。
3、充电中,LED指示灯红灯长亮。
4、充电完成,LED指示灯红灯自动熄灭。

（三）功能操作
已连接手机，待机状态下，连按2次电源键，可唤醒语音助手。

1、接打电话
• 拨打电话：连按2次电源键,听到提示音后，打电话给** (通讯录里面名字)或者对方手机号码，即可呼出电话；
• 接听电话：单按电源键,即可接听电话；
• 挂断电话：单按电源键,即可挂断电话；
• 重拨：连按3次电源键,即可重拨最后一个通话记录。
2、欣赏音乐
• 精准选歌：连按2次电源键,听到提示音后说，播放音乐（如上海滩）,即可调用并播放手机里面的歌曲；
• 随机放歌：连按2次电源键,听到提示音后说，播放音乐，即可调用并随机播放手机里面的歌曲；
• 播放下一曲：连按2次电源键；
• 播放上一曲：连按3次电源键；
• 暂停播放：单按电源键。
3、播放音乐与拨打电话之间切换
• 当在听音乐过程中需要拨打电话时,先单按电源键将音乐暂停,然后连按2次电源键，听到提示音后即可拨打电话。
4、导航
• 开启导航：连按2次电源键,听到提示音后说,帮我导航到** 地方,然后根据眼镜提示音进行语音操作；
• 关闭导航：连按2次电源键,听到提示音后说，退出导航。
5、脱机拍照功能等
• 打开相机状态下,单按电源键即可拍照。

产品保修凭证

产品保修期内出现非人为损坏的性能故障可以享受下列三包服务：
• 自收货之日起7日内,产品出现非人为损坏的性能故障,用户可选择一次性退换货款、更换同型号同规格的产品。
• 自收货之日起15日内,产品出现非人为损坏的性能故障,用户可选择更换同型号同规格的产品。
• 自收货之日起一年内,产品出现非人为损坏的性能故障，用户可寄商家维修。

属于下列情况不在“三包”服务范围之内：
• 未经授权的维修、误用、碰撞、疏忽、滥用、进液、事故、改动或撕毁、涂改产品标贴、封条。
• 超过“三包”服务有效期的。
• 因火灾、水灾、雷击等不可抗力造成的损坏。
• 因人为原因导致的产品性能故障。
• 未按产品说明书要求使用而造成损坏的。

保修卡

尊敬的用户，本保修卡是您将来申请保修的凭证，请您配合销售商填写并妥善保管备用。

用户信息	用户姓名	
	联系电话	
	通讯地址	
	电子邮箱	
	邮政编码	
产品信息	产品名称	
	产品型号	
	产品条码	
销售商信息	名　　称	
	地　　址	
	联系电话	
	邮政编码	
	销售日期	
	发票号码	
备注		

蓝牙连接示意图

进入设置

选择蓝牙选项



确保蓝牙开关处于 ON状态
搜索设备名：**J2**
点击蓝牙名进入连接

蓝牙连接成功

KRECO

Multifunctional Smart Glasses

KRE-K2-1 Instruction Manual

1.Long press the power button for 3S to boot.

2.Press the power button twice to the next song.

3.Press the power button 3 times to the previous song.

4.Press 4 times to switch between Chinese and English mode

(Used when the device is turned on and not connected).

• Disclaimer

First of all,thank you for using out products! Please read this manual before using and use this product correctly.For the better service.changes due to the performance and functionality of the product will be revised without notice.Open-ear smart audio glasses.This product is a Bluetooth speaker withstereo function,easy to operate, stylish and practical,easy too carry.

• Product Introduction

Multifunctional smart glasses use Bluetooth chips, compatible with mainstream brand mobile phones and tablets and other Bluetooth devices, support aptX audio decoding technology, achieve CD-level high-quality sound quality, long-lasting battery life, left and right double speakers, open directional pronunciation, and barrier-free reception of external sounds. The surrounding environment information can be obtained at all times, which is safe, intelligent, healthy and convenient.

• Packing List

Audio glasses,Glasses charging cable, Instruction manual,Glasses cleaning cloth.

• Product Parameters

Frame Material: PC
Lens Material: PC
Lens Color: Transparent color/
Sunglasses color (Multiple options)
Bluetooth Protocol: 5.0
Charging Time: 2H
Use Time: 6H
Standby Time: 180H(Bluetooth connection)
Battery Capacity: 120mAh
Sound Channel: Double speakers,
　　stereo sound
Charging Voltage And Current: DC5V/1A
The maximum charging current
is 160mAh

• Warm Prompt

Charging time: 1-2 hours.
When not in use for a long time,charge the battery at least once every 2 months.

• Directions For Use

(1)Glasses switch machine and matching.

Turn on the bluetooth device such as the mobile phone,press and hold the power button for 3 seconds,the glasses voice prompts [Starting], and the LED indicator light keeps flashing at this time;after the connection with the bluetooth device is successful,the indicator light goes out.
(For detailed operation, please refer to the bluetooth connection diagram on the last page.)

(2)Charging and alarm.

1.Low power alarm,voice prompts [low battery charge please],the LED indicator continues to blink 3 seconds interval 5 seconds.
2.Low power off,voice prompts [shutdown], the LED indicator for 1second long.
3.During charging,the red light of the LED indicator is long.
4.When the charging is completed,the LED indicator red light will automatically go out.

(3)Functional Operation

The phone is connected, and in the standby mode, press the power button twice to wake up the voice assistant.

1.Making and receiving calls
• Make a phone call: Press the power button twice in succession,and when you hear the prompt tone,call ** (the name in the address book) or the phone number of the other party, then you can make a phone call;
• Answer the call: Single press the power button to answer the call;
• Hang up the call: Single press the power button to hang up the call;
• Redial: Press the power button three times in succession to redial the last call record;

2.Listen to music
• Accurate song selection: Press the power button two times and say "Play music" after hearing the prompt sound (such as Shanghai Tang), then you can call and play the songs inside the phone;
• Random play: Press the power button two times,and when you hear the prompt sound, say "Play music",you can call and randomly play the songs inside the phone;
• Play the next song: Press the power button two times;

• Play the last song: Press the power button three times in a row;
• Pause playback: Single press the power button.
3.Switch between playing music and making phone calls.
• When you need to make a call while listening to music,first press the power button to pause the music,and then press the power button twice to make the call after hearing the prompt tone.
4.Navigation
• Turn on the navigation: press the power button twice, say "Help me navigate to the ** position" after hearing the prompt,and then perform voice operations according to the prompt sound of the glasses;
• Turn off the navigation: Press the power button twice,and then say "Exit the navigation" after hearing the prompt tone.
5.Offline camera function,etc
• When the camera is turned on,single press the power button to take a photo.

• Tips

1.Please read the instructions carefully before using this product and keep this manual.
2.For the first time,please fully charge this glasses.
3.If the glasses does not charge for a long period of time (more than two weeks),charge it before use.

• Warning

1.Do not dismantle or repair this product for any reason,as this may result in fire. Electronic breakdown or even complete damage to the product.
2.Do not place the device in an environment where the temperature is too low or too high(below 0°C or above 45°C).
3.Do not get the product wet with liquid or immerse in liquid.
4.Do not expose the glasses to the sun for a long time,otherwise it will be easily deformed,broken and broken.

• Important Safety Information

•Please read all safety information before using this equipment to ensure correct and safe use.

• Use of a power source,charger or battery that is not approved by this manufacturer may cause fire, explosion or other hazards.
• Use accessories approved by this manufacturer and compatible with this model. Please use the device within the temperature range of 0°C-35°C,and store the device and its accessories within the temperature range of -20°C - 55°C.When the ambient temperature is too high or too low,it may cause equipment failure.
• If the device uses a non-removable internal battery,do not replace the battery yourself to avoid damaging the battery or device. The battery can only be replaced by an authorized service center.
• Please charge according to the charger specified by the manufacturer.Using a charger with other voltages may cause leakage,fire or damage to the device and charger.
• If charging is complete .disconnect the charger from the device the unplug the charger from the power outlet.Do not charge more than 12 hours.
• Please do not throw the old battery into your household waste for disposal.If the battery is improperly handled,it may cause the battery to catch fire and explode.Please dispose of this device,battery and other accessories in accordance with local regulations.

• The battery is forbidden to be disassembled,impacted,squeezed or put into fire .If there is serious expansion,do not continue to use it.
• Do not short the battery metal contacts, resulting in a short circuit hazard,avoiding battery burns and other personal injury caused by burns and burns.
• Do not expose to high temperatures. Overheating of the battery may cause an explosion.
• Do not disassemble,collide,squeeze the battery,avoid causing leakage,overheating, explosion; do not put the battery into the fire,otherwise it will cause fire or explosion.
• If the battery is severely inflated,do not continue to use it.
• Please keep the equipment dry.
• Do not repair any product yourself.If the device or any part of it does not work properly.
• When connecting other devices,please refer to the connection method of the user manual.Do not connect unsupported devices at will.To avoid hearing damage, do not use high volume for long periods of time.

• Caution

1.Please follow the relevant laws and regulations and do not use headphones in the following environments.

2.For example,gas stations,oil depots, chemical warehouses,etc.,where flammable or explosive oil or chemicals are stored,it is strictly forbidden to use equipment.Do not use this equipment in hospital operating rooms, emergency rooms, intensive care units,etc.;to avoid interference with medical equipment, please keep away from card iac pacemakers, hearing aids, implanted cochlea and other medical equipment when using this equipment.Please keep this equipment. More than 15cm between the pacemaker and the pacemaker.
3.To use this device near personal medical devices,consult your physician and device manufacturer.
4.Please observe all safety warnings and regulations regarding the use of this device while driving.
5.To avoid lightning strikes during thunderstorms, do not use outdoors.
6.Do not call while charging.
7.Do not use the charger in a place with high humidity such as a bathroom,as this may result in electric shock,personal injury, fire and damage to the charger.
8.Please comply with the relevant legal provisions that are expressly prohibited in any environment.

Schematic diagram of Bluetooth connection

Go to settings



Select the Bluetooth option



Make sure the Bluetooth switch is ON, search for the device name: **J2**, click the Bluetooth name to enter the connection.



The bluetooth connection is successful.